

**Adjustable time zones**

This radio-controlled watch has four adjustable time zones.

**Date Display**

Display of the current date with analogue watches.

**Date and Weekday Display**

Display of the date and day of the week with analogue watches.

**Display of The Day in Different Languages**

The name of the day can be displayed in different languages.

**Date Alert**

A mark appears on the display when a preset date is reached.

**Day Counter**

Shows the number of days from the current date to another date.

STOPWATCH FUNCTIONS**Stopwatch**

Accurate measurement of elapsed time with the touch of a button. The fraction indicates the unit of measurement, while the time figure indicates the maximum time measurement.

**Referee function (referee stop watch)**

By using the referee function you can determine the amount of injury time. The actual amount of playing time and the total time is displayed simultaneously.

**Pacemaker (distance)**

An individually adjustable progression of signals helps you maintain your running rhythm. Just enter the length of your stride, additionally you will be given the approximate distance covered.

**Marathon Simulator**

Uses your best time at 5 or 10 km to simulate the time required for a full marathon.

COUNTDOWN TIMER**Countdown Timer**

A stopwatch that counts backwards: When 0 minutes, 0 seconds is reached, the timer emits a 10-second signal tone.

**Countdown Timer with automatic repeat function**

As soon as the countdown stopwatch reaches 0 minutes and 0 seconds and indicates this by emitting a signal tone, it automatically returns to the preset time value and begins counting backwards again. This function is particularly useful for people who need to take regular medication (e. g. every half hour). The digit within the icon gives the number of repetitions.

**Yacht Timer**

The yacht timer is used to time the start of regattas. The countdown period can be set from 1 to 10 minutes. An acoustic signal is emitted after each minute has elapsed and then once a second for the last ten seconds.

**Timer for measuring intervals**

The timer allows you to define and set up to nine individual countdown times to run successively. This is helpful for things like interval training (e.g. 3 minutes of running, 2 minutes of walking, a 1-minute break).

**Preset Timer**

Allows you to call up and apply preset times for different kinds of sports.

ALARM FUNCTIONS

The daily alarm sounds each day at the time you set. The value indicates how many daily alarms are available. The hourly time signal causes the watch to beep every hour on the hour.

**Beeper Alarm**

Beeper tone alarm sounds at the time you set.

**Multi Alarm, Hourly Time Signal**

A total of four different alarm types are available: 1. Daily alarm; 2. Monthly alarm; 3. Alarm for a particular time each day of a particular month; 4. Date alarm. The digit within the icon indicates the maximum number of alarm settings.

**Snooze Feature**

Each time you stop the alarm, it sounds again after a few minutes.

**Vibration Alarm**

Serves as a silent alarm.

**Bell Alarm**

A bell tone alarm sounds at the time you set.

BATTERY FUNCTIONS**Battery Level Indicator**

Indicator shows the current battery level.

**Low Battery Warning**

A warning appears on the display whenever the battery power drops below a certain level.

